
Guide Rail
Guide Rail
Assembly
2 1/4"
Miter Slot
Bosch 4100XC-10
Table Top
Miter Slot


Assembly
Bottom
ARRANGE THE GUIDE RAILS
SO THAT THE 12 1/2" SPACING
IS USED HERE
12 1/2"
1/2"
ENDS OF GUIDE RAILS
OFFSET FROM EDGE OF BASE



Rockler Aluminum Miter Bar Part No. 26232


30"
2 1/4"
1 1/4"
EDGE OF SAW TOP
ALIGNED TO THIS
LINE ON THE BOSCH
4100XC-10 SAW
1/2" PLYWOOD
ANTICIPATED INSIDE
EDGE OF FRONT FENCE
1 7/16"
1 1/2" DIA
2 PLACES
Base
19 1/8"
12"
3 9/16"
1 7/16"
MOUNTING HOLES
FOR STORAGE ON HOOKS
2 PLACES
ANTICIPATED INSIDE
EDGE OF REAR FENCE


27 7/8"
26 5/8"
18 7/16"
15 15/16"
11 15/16"
9 7/16"
1 1/4"
5"
3 3/4"
2 1/2"
1 1/4"
Blade Guard Top
3/4" PLYWOOD
ALL RADII 1 1/4"
2"
1 3/4"
Rear Fence
CUT A 1/8"X1/8" RABBET
ALONG THE BOTTOM EDGE
OF THE REAR FENCE WHERE
THE FENCE WILL PRESS
AGAINST THE WORKPIECE
2 STACKED PIECES
OF 3/4" PLYWOOD
Blade Guard Side
2"x3"x3/4" PLYWOOD
Blade Guard Side
2"x3"x3/4" PLYWOOD


27 7/8"
26 5/8"
18 7/16"
15 15/16"
11 15/16"
9 7/16"
1 1/4"
4 1/2"
3 1/4"
2"
3/4"
ALL RADII 1 1/4"
Front Fence
2 STACKED PIECES
OF 3/4" PLYWOOD


28" PATTERN SIZE
5" REAR FENCE
4 1/2" FRONT FENCE
Fence
Square Pattern
-
Each Square is 1/2"
LET THIS EDGE BE A FACTORY-CUT
EDGE OF YOUR PATTERN MATERIAL
27 7/8" LENGTH OF FENCE